

Blue Key Conservation Instructions:

Start with two Blue Key blanks or a blank and a pre-cut key.

IF CHANGING ONE CYLINDER

Cut client bitting on Blue Key blank.

Turn the key to 11:00 change position. Remove key in 11:00 position.

Optional, pick lock to the 11:00 position.

Modify the existing Blue Key cuts, cut a fresh Blue Key, or use a pre-cut Blue Key, then reinsert into lock.

Cycle the lock a couple times and remove the key at the 12:00 position.

Lock will become the modified key bitting.

You will now have a pre-cut key to use for the next occasion.

Second Blue Key blank is still available for the next occasion.

IF CHANGING MORE THAN ONE CYLINDER

Cut client bitting on Blue Key blank.

Turn the key to 11:00 change position. Remove key in 11:00 position.

Optional, pick lock to the 11:00 position.

Grab another pre-cut Blue Key and insert the key into the lock.

Cycle the lock a couple times and remove the key at the 12:00 position.

Lock will become the newly inserted key bitting.

Repeat for the remaining lock cylinders.

You will now have two pre-cut keys to use for the next occasion.

You will need another Blue Key blank for the next occasion.

Keep a set of two blanks or one blank with a pre-cut or two in your toolbox.